

Standing Seam Roof Panels Installation

REQUIRED TOOLS & MATERIALS

- Drill
- #30 drill bit
- Pop rivets (supplied by B.I.G.)

INSTRUCTIONS

1. After the booth is installed, remove the lifting eyes.
2. The roof panels are numbered on the back with corresponding numbers marked on the booth.
3. Slide the panel into the corresponding numbered locations—See Fig 1
4. Bend the retainer clip tabs down to lock in the panel —See Fig 2
5. Snap the standing seam ribs over the panel seams and retainer clips—See Fig 3
6. Drill a small hole at the end of the standing seam rib. See Fig 4
7. Place pop rivet in rib to secure the rib and panel.
8. Fold the rib tab over. See other ribs for reference. See Fig 5

Use existing installed panels as a guide for pop rivet locations.

For further assistance contact Gary Henderson (626) 448-1449 ext 114

