


BOOTH OFF-LOADING INSTRUCTIONS

Forklift Handling Guidelines

- Forks must extend the full width of the booth
- Size the capacity of your forklift based on the weight distributed around the perimeter of the booth and on site reach needs.



BOOTH OFF-LOADING INSTRUCTIONS

Forklift Handling Guidelines

- **Forks must extend the full width of the booth**
- **Size the capacity of your forklift based on the weight distributed around the perimeter of the booth and on site reach needs.**

